


–weishaupt–

manual

Installation and operating instruction



| | | |
|----------|---|-----------|
| 1 | User instructions | 5 |
| 1.1 | User guide | 5 |
| 1.1.1 | Symbols..... | 5 |
| 1.1.2 | Target group | 5 |
| 1.2 | Guarantee and Liability..... | 6 |
| 2 | Safety notes | 7 |
| 2.1 | Commissioning | 7 |
| 2.1.1 | Electrical connection..... | 7 |
| 2.2 | Alteration to the construction of the equipment..... | 7 |
| 2.3 | Shutdown..... | 8 |
| 2.4 | Maintenance, repair and modification | 8 |
| 2.5 | Disposal..... | 8 |
| 3 | Product description | 9 |
| 3.1 | Type key | 9 |
| 3.2 | Technical data | 10 |
| 3.2.1 | Inputs..... | 10 |
| 3.2.2 | Outputs | 11 |
| 3.2.3 | Power supply | 12 |
| 4 | Installation | 15 |
| 5 | Electrical connection | 17 |
| 6 | Operation | 18 |
| 6.1 | Front view | 18 |
| 6.2 | Operating level..... | 19 |
| 6.3 | Error list | 20 |
| 6.4 | Error status (error status 3 - 9 only with error AdA.H):..... | 21 |
| 6.5 | Self-optimisation (automatic adaption of control parameters)..... | 22 |
| 6.6 | Optimisation aid for manual optimisation | 24 |
| 6.7 | Manual operation | 26 |
| 6.8 | Parameter setting and configuration | 27 |
| 7 | Configuration level | 28 |
| 7.1 | Configuration with Quick | 28 |
| 7.1.1 | Function: Signalling device with change-over switch | 30 |
| 7.1.2 | Function: 3-point step controller..... | 31 |
| 7.1.3 | Function: Switching controller..... | 32 |
| 7.2 | Configuration without Quick (Quick = OFF)..... | 33 |
| 8 | Parameter level | 40 |
| 8.1 | Input scaling (only visible with Quick= OFF) | 42 |
| 8.1.1 | Input Inp.1..... | 42 |
| 8.1.2 | Input InP.2 | 42 |
| 9 | Calibration level | 43 |

| | | |
|-----------|---|-----------|
| 9.1 | Offset correction | 44 |
| 9.2 | 2-point correction | 46 |
| 10 | Optional plug-in modules | 48 |
| 10.1 | Optional modules and their function | 48 |
| 10.1.1 | Automatic recognition of optional modules | 49 |
| 10.1.2 | Preparation for installing or removing optional modules | 49 |
| 10.1.3 | Removing/replacing optional modules | 50 |
| 10.1.4 | Inserting the device into the housing | 51 |
| 11 | Maintenance..... | 52 |
| 11.1 | Reset to factory setting | 52 |
| 12 | Notes..... | 53 |








1 User instructions

1 User instructions

These installation and operating instructions form part of the unit and must be kept on site at all times. They are supplemented by the installation and operating instructions for combustion manager W-FM 100/200.

1.1 User guide

1.1.1 Symbols

| | |
|---|--|
|  DANGER | Immediate danger with high risk. Non observance can lead to serious injury or death |
|  WARNING | Danger with medium risk. Non observance can lead to environmental damage, serious injury or death |
|  CAUTION | Danger with low risk. Non observance can cause damage to the equipment and injury to personnel |
|  | Important information |
|  | Requires direct action |
|  | Result after an action |
|  | Itemisation |
| ... | Range |

1.1.2 Target group

These installation and operating instructions are intended for the operator and qualified personnel. They should be observed by all personnel working on the unit.

Work on the unit must only be carried out by personnel who have the relevant training and instruction.

Persons with limited physical, sensory or mental capability may only work on the unit if they are supervised or have been trained by an authorised person.

Children must not play with the unit.

1 User instructions

1.2 Guarantee and Liability

Guarantee and liability claims for personal and equipment damage are excluded, if they can be attributed to one or more of the following causes:

- Non approved application of the unit
- Non-observance of the installation and operating instructions
- Operating the unit with faulty safety equipment
- Continual operation despite a fault
- Improper installation, commissioning, operation and servicing of the unit
- Alterations to the unit
- The installation of additional components, which have not been tested with the unit
- The installation of combustion chamber inserts, which impede full flame formation
- Repairs, which have been carried out incorrectly
- The use of non original Weishaupt parts
- Unsuitable fuels
- Defects in the inlet lines
- Acts of God

2 Safety notes

2 Safety notes



Warning

If the device is damaged to an extent that safe operation can not be guaranteed, it must not be used.

This device was built and tested in compliance with VDE 0411-1 / EN 61010-1 and was delivered in safe condition. The device complies with the European Directive 89/336/EU (EMV) and is provided with CE labelling.

The device was tested before delivery and has passed the tests required by the test schedule. To maintain this condition and to ensure safe operation, the user must follow the instructions and warnings given in this operating manual. The device is intended exclusively for use as a measurement and control instrument for technical installations.

2.1 Commissioning

Prior to switching on the device, ensure that the following points have been observed:

- Ensure that the supply voltage corresponds to the specifications given on the name plate.
- All covers required for contact protection must be fitted.
- If the controller is connected with other devices in the same signal loop, ensure that the equipment in the output circuit is not affected prior to switching on.
- The device must only be operated once it has been installed.
- The temperature restrictions specified for controller operation must be met prior to and during operation.

2.1.1 Electrical connection

For all work carried out on live parts:

- Observe the accident prevention instruction BGV A3 and adhere to local directives
- Use tool in accordance with EN 60900



WARNING

Live parts and terminals may be exposed when opening the device or when removing covers or components. Connection points may also be live.

The device must be disconnected completely from the power supply prior to starting this work.

The electrical wiring must conform to local standards and regulations (e.g. VDE 0100). The input measurement and control cables must be kept separate from signal and power supply cables.

2.2 Alteration to the construction of the equipment

All conversions require written approval from Max Weishaupt GmbH.

- No additional components may be fitted, which have not been tested for use with the equipment
- Do not use combustion chamber inserts, which inhibit flame formation
- Use only original Weishaupt replacement parts

2 Safety notes

2.3 Shutdown

If the device is to be taken out of operation, the power supply must be switched off at all poles. The device must be secured against inadvertent operation. If the device is interconnected with other devices and / or facilities, the effects on these should be considered and appropriate precautions should be taken prior to switching off the device.

2.4 Maintenance, repair and modification

The devices require no special maintenance.



Live parts and terminals may be exposed when opening the device or when removing covers or components. Connection points may also be live.

The device must be disconnected completely from the power supply prior to starting this work.



When opening the device, components which are sensitive to electrostatic discharge (ESD) may be exposed.

The following work may only be carried out at workstations with suitable ESD protection. Modifications, maintenance and repair work may only be carried out by trained and authorised personnel.

The service department is available to carry out this work.

After completing this work, the device should be closed and all covers and components should be refitted.

Check, if information given on the name plate has to be changed and correct the information if required.

2.5 Disposal

Dispose of all materials used in a safe and environmentally friendly way. Observe local regulations.

3 Product description

3 Product description

3.1 Type key

| | | | | | | |
|--|---|---|---|--|--|---|
| Option 1 | | | | | | |
| Relay (switch-over) | R | | | | | |
| Option 2 | | | | | | |
| Double Relay | D | | | | | |
| Option 3 | | | | | | |
| Not fitted | | 0 | | | | |
| Linear mA/VDC output | | | L | | | |
| RS485 | | | C | | | |
| Relay Output | | | R | | | |
| DC Drive Output for SSR | | | S | | | |
| Option 4 | | | | | | |
| Not fitted | | 0 | | | | |
| 2. Universal analogue input | | | I | | | |
| Manuals | | | | | | |
| Single Pack with Concise Manual | | 0 | | | | |
| Bulk Pack with 1 Concise Manual per unit - (Minimum 20 pieces) | | 1 | | | | |
| Bulk Pack No Manual - (Minimum 20 pieces) | | 2 | | | | |
| Approvals | | | | | | |
| Standard (CE certified) | | | | | | 0 |
| cULus certified | | | | | | U |
| GL (German Lloyd) certified | | | | | | G |

Option Modules

| | | | | | | | |
|-----------------------------|-------------|----------|----------|----------|----------|----------|----------|
| Model Code | KS20 | - | 1 | O | P | - | X |
| Option 3 | | | | | | | |
| 2. Universal analogue input | | | | | | | L |
| RS485 | | | | | | | C |
| Relay Output | | | | | | | R |
| DC Drive Output for SSR | | | | | | | S |

3 Product description

3.2 Technical data

3.2.1 Inputs

ACTUAL VALUE INPUT INP1

| | |
|----------------------------|------------------------------------|
| Resolution: | > 14 Bit (20.000 steps) |
| Decimal point: | 0 to 3 digits behind decimal point |
| Limit frequency: | 2 Hz (analogue) |
| Digital input filter: | adjustable 0.0...100.0 s |
| Scanning cycle: | 100 ms |
| Measured value correction: | 2-point or offset correction |

Thermocouples

| | |
|------------------------------|--------------------------|
| See table 1 (page 13) | |
| Input resistance: | $\geq 1 \text{ M}\Omega$ |
| Effect of source resistance: | $1 \mu\text{V}/\Omega$ |
| Temperature compensation: | internal |

Sensor break monitoring

| | |
|-----------------|----------------------|
| Sensor current: | $\leq 1 \mu\text{A}$ |
| Output action | can be configured |

Resistance thermometer

| | |
|---------------------------|-------------------------|
| See table 2 (page 14) | |
| Connection: | 2- or 3-wire |
| Cable resistance: | max. 30 Ohm |
| Input circuit monitoring: | break and short circuit |

REMOTE TRANSMITTER 50-30-50 Ω

Current and voltage measuring ranges

| | |
|-------------------------------|---|
| See table 3 (page 14) | |
| Measurement start, meas. end: | anywhere within the measuring range |
| Scaling: | optional -1999...9999 |
| Linearisation: | 16 segments, adaptable with BlueControl |
| Decimal point: | adjustable |
| Input circuit monitoring: | 12.5% below meas. start (2mA, 1V) |

ADDITIONAL INPUT INP2

| | |
|-----------------|----------|
| Resolution: | > 14 Bit |
| Scanning cycle: | 100 ms |

Current measuring range

| | |
|------------------------|--|
| Technical data as INP1 | |
|------------------------|--|

3 Product description

Potentiometers

| | |
|---------------------------|-------------|
| See table 2 (page 14) | |
| Connection: | 3-wire |
| Cable resistance: | max. 30 Ohm |
| Input circuit monitoring: | break |

Control inputs DI2,DI3

Can be configured as switch or push button! Connection of a potential-free contact suitable for switching "dry" circuits.

| | |
|-------------------|--------|
| Switched voltage: | 3.3 V |
| Current: | ≤10 mA |

TRANSMITTER SUPPLY UT (optional)

| | |
|--------|----------------|
| Power: | 22 mA / ≥ 18 V |
|--------|----------------|

GALVANIC ISOLATION

| | |
|--------------------------|---|
| Safety isolation | EN 61010 |
| Function isolation | EN 61010 |
| Power supply connections | Actual value input INP1 Additional input INP2 Digital inputs di2,3 Transmitter supply UT |
| Relay outputs OUT1,2 | |
| Relay outputs OUT3 | |

3.2.2 Outputs

RELAY OUTPUTS OUT1, OUT2

| | |
|-----------------------------|--|
| Contact type: | 2 contacts with common connection |
| Maximum switching capacity: | 500 VA, 250 V, 2A at 48...62 Hz, resistive load |
| Minimum switching capacity: | 6V, 1 mA DC |
| Electrical operating life: | 800.000 switch cycles at max. switching capacity |

RELAY OUTPUT OUT3

| | |
|-----------------------------|--|
| Contact type: | Potential-free change-over contact |
| Maximum switching capacity: | 500 VA, 250 V, 2A at 48...62 Hz, resistive load |
| Minimum switching capacity: | 5V, 10 mA AC/DC |
| Electrical operating life: | 600.000 switch cycles at max. switching capacity |



When connecting a control contactor to OUT1...OUT3, an RC protective circuit meeting the requirements stipulated by the manufacturer must be fitted to the contactor to prevent high voltage peaks.

3 Product description

3.2.3 Power supply

AC VOLTAGE

| | |
|----------------------------|----------------------------------|
| Voltage: | 100...240 V _{AC} +/-10% |
| Frequency: | 50...60 Hz |
| Power consumption, approx. | 11 VA |

BEHAVIOUR AT POWER FAILURE

| | |
|--|-----------------------------|
| Configuration, parameters and setpoints set, operating mode: | Permanent storage in EEPROM |
|--|-----------------------------|

AMBIENT CONDITIONS

Type of protection

| | |
|---------------|-----------------|
| Device front: | IP 65 (NEMA 4X) |
| Housing: | IP 20 |
| Connections: | IP 00 |

Permissible temperatures

| | |
|----------------------|------------|
| Operation: | 0...55°C |
| Start-up time: ε | 15 minutes |
| Limit for operation: | -20...60°C |
| Storage: | -20...70°C |

Humidity

75% annual average, no condensation

Shock and vibration

Vibration Fc (DIN 68-2-6)

| | |
|---------------------------------|-----------------------------|
| Frequency: | 10...150 Hz |
| Device in operation: | 1g or 0.075 mm |
| device not operating: | 2g or 0.15 mm |
| Shock test Ea (DIN IEC 68-2-27) | Shock: 15g / duration: 11ms |

Electromagnetic compatibility

Complies with EN 61 326-1 (for continuous, non-monitored operation)

GENERAL

Housing

| | |
|---------------------|------------------------------|
| Material: | ABSAF 305 |
| Flammability Class: | UL 94 VO, self-extinguishing |

Plug-in module, inserted from the front

3 Product description

Safety

| | |
|--|--|
| Complies with EN 61010-1 (VDE 0411-1): | Overvoltage Category II Contamination Class 2 Operating Voltage Range 300 V Protection Class II |
|--|--|

Electrical connections

Plug-in screw terminals

Installation

Panel mounted, close proximity mounting possible,
Mounting position: optional, weight: 0.2 kg

Accessories supplied with the device

Operating manual

Table 1 Thermocouple measuring ranges

| Thermocouple type | | Measuring range | | Accuracy | Resolution (Ø) |
|-------------------|----------------|-----------------|------------------|----------|----------------|
| L | Fe-CuNi (DIN) | -100...900°C | -148...1652°F | ≤ 2K | 0.1 K |
| J | Fe-CuNi | -100...1200°C | -148...2192°F | ≤ 2K | 0.1 K |
| K | NiCr-Ni | -100...1350°C | -148...2462°F | ≤ 2K | 0.2 K |
| N | Nicrosil/Nisil | -100...1300°C | -148...2372°F | ≤ 2K | 0.2 K |
| S | PtRh-Pt 10% | 0...1760°C | 32...3200°F | ≤ 2K | 0.2 K |
| R | PtRh-Pt 13% | 0...1760°C | 32...3200°F | ≤ 2K | 0.2 K |
| T | Cu-CuNi | -200...400°C | -328...752°F | ≤ 2K | 0.05 K |
| C | W5%Re-W26%Re | 0...2315°C | 32...4199°F | ≤ 2K | 0.4 K |
| D | W3%Re-W25%Re | 0...2315°C | 32...4199°F | ≤ 2K | 0.4 K |
| E | NiCr-CuNi | -100...1000°C | -148...1832°F | ≤ 2K | 0.1 K |
| B * | PtRh-Pt6% | 0(100)...1820°C | 32(212)...3308°F | ≤ 2K | 0.3 K |

* Specifications valid from 100°C

3 Product description

Table 2 Resistance transducer measuring ranges

| Type | Meas. current | Measuring range | | Accuracy | Resolution (Ø) |
|---------------|---------------|-----------------|---------------|----------|----------------|
| Pt100 | 0.2mA | -200...100°C | -140...212°F | ≤ 1K | 0.1K |
| Pt100 | 0.2mA | -200...850°C | -140...1562°F | ≤ 1K | 0.1K |
| Pt1000 | | -200...200°C | -140...392°F | ≤ 2K | 0.1K |
| KTY 11-6 * | | -50...150°C | -58...302°F | ≤ 2K | 0.05K |
| Special | | 0...4500 | | ≤ 0.1 % | 0.01 % |
| Special | | 0...450 | | | |
| Potentiometer | | 0...160 | | | |
| Potentiometer | | 0...450 | | | |
| Potentiometer | | 0...1600 | | | |

* Or Special

Table 3 Current and voltage measuring ranges

| Measuring range | Input resistance | Accuracy | Resolution (Ø) |
|-----------------|------------------------------------|----------|----------------|
| 0-10 Volt | ~ 110 kW | ≤ 0.1 % | 0.6 mV |
| 0-20 mA | 49 W (voltage requirement β 2.5 V) | ≤ 0.1 % | 1.5 mA |

4 Installation

4 Installation



Please ensure that the inside of the mounting plate corresponds to the operating temperature of the device and sufficient ventilation is provided to prevent overheating.

Please DO NOT remove the safeguard/seal from the mounting plate as this can lead to the device becoming jammed in the mounting plate.

The mounting plate must be solid and up to 6.0 mm thick. The required cut-out is shown below. Several devices with the following dimensions can be installed side by side:

Devices: (48n - 4) mm or (1.89n - 0.16) inches.




Fig. 1: Installation dimension


Installation dimensions

The installation depth with terminals plugged in is 110mm.

Hold the device firmly in position (applying pressure only to the front bezel)


4 Installation

Fig. 2 : Orientation



- ❶ Mounting plate
- ❷ Device housing
- ❸ Locking groove
- ❹ Seal

Fig. 3: Mounting bracket



- ❺ Slide the mounting bracket over the back of the device housing, until the spring tongue engages in the locking groove

After installing the device in the mounting plate, it can be removed from its housing if required (see "Fitting and removing optional modules").




The lugs of the mounting bracket will lock on both sides or on the top / bottom of the device housing. If you are installing multiple units side by side, use the locking grooves on the top / bottom.

5 Electrical connection

5 Electrical connection

Fig. 4: Electrical connection



Connection of input INP1

Input for variable x1 (actual value).

- a Thermocouple
- b Resistance thermometer (Pt 100/Pt1000/KTY)
- c Remote transmitter 50-30-50 Ω
- d Voltage 0..10V (* : see wiring diagram)
- e Pressure transducer (3-wire connection)
- f Pressure transducer (2-wire connection)
- g Current 0..20mA (** : see wiring diagram)

Connection of input INP2

See input INP1.

Connection of input s di2/di3

Digital input di2 for external change-over switching between SP and SP.2/SP.e (SP/SP.2).

Digital input di3, ext. change-over switching 3-point step controller/signalling device (DPS/SG).

6 Operation

6 Operation

6.1 Front view




Fig. 5: Front view

- ❶ Actual value display
- ❷ Setpoint, variable, parameters
- ❸ Status of switching outputs
- ❹ Manual operation
- ❺ Setpoint SP.2 or SP.e is effective
- ❻ Controller operates as signalling device
- ❼ Function key
- ❽ Changing the setpoint value in automatic or in manual operation
- ❾ Acknowledges value changes or shows the next parameter/value

The actual value is always displayed in the upper display. In the parameter and configuration level and in the Error list the bottom display changes cyclically between the parameter to be set and the parameter value.

6 Operation

6.2 Operating level

The operating level comprises two views for setpoint and controller output value. It can be extended with two further levels:

- Extended operating level
- Function level

The content of the extended operating level and the function level is determined means of the Engineering Tool. Parameters, which are used frequently or the display of which is important, can be copied to the extended operating level.




Fig. 6: Operating level

The error list is visible only if an error entry is present. An active entry in the error list is displayed in the second row of the display which flashes red/green.

| Err status | Significance | Proceed as follows |
|--------------------|-----------------|--|
| 2. row flashes red | error present | - determine the error type in the error list via the error number - rectify error |
| .. is red | error rectified | - acknowledge the alarm in the error list by pressing Δ - or ∇ key - the alarm entry is deleted |
| .. is green | no error | |

All errors can also be reset in the function level with Err ⏻ rSET (if configured).

6 Operation**6.3 Error list**

| Name | Description | Cause | Possible remedial action |
|-------------|----------------------------------|---|---|
| E.1 | Internal error, unrecoverable | e.g. defective EEPROM | - Contact PMA Service - Return device |
| E.2 | Internal error, recoverable | e.g. EMC interference | - Briefly disconnect device from mains - Run test and power cables separately - Use contactor suppression |
| E.4 | Internal error, optional modules | HW coding does not match current HW configuration | - Contact PMA Service - Return device or check optional modules |
| FBF.1/2 | Sensor break input 1/2 | Sensor defective wiring fault | Replace INP1 / 2 sensor Check INP1 / 2 connection |
| Sht.1/2 | Short circuit input 1/2 | Sensor defective wiring fault | Replace INP1 / 2 sensor Check INP1 / 2 connection |
| POL.1 | Polarity error input 1 | Wiring fault | Interchange INP1 wiring |
| AdA.H | Adaption alarm heating (ADAH) | see error list status Heating Adaption | see error list status Heating Adaption |





6 Operation


6.4 Error status (error status 3 - 9 only with error AdA.H):

| Err status | Significance | Reaction |
|------------|---|--|
| 1 | Stored error | Entry is deleted once acknowledged |
| 2 | Existing error | Change to error status 1 after error has been rectified |
| 3 | Faulty control action | Reconfigure controller (inverse/direct) |
| 4 | No reaction of the control variable | Perhaps the control circuit is not closed: check sensor, connections and process |
| 5 | Low reversal point | Let process cool down and start new adaption attempt |
| 6 | Danger of exceeding setpoint (parameter determined) | If necessary increase (inverse) or decrease (direct) setpoint |
| 7 | Output step change too small | Let process cool down and start new adaption attempt |
| 8 | Setpoint reversal too small | Increase (inverse) or decrease (direct) setpoint |
| 9 | Impulse attempt failed | Perhaps the control circuit is not closed: check sensor, connections and process |

The function level serves for the enhanced operation off he device. Its content is determined by configuration (LOGI):

- Err No resetting of error list
- Erst Resetting of error list
- SP Internal setpoint active
- SP.E External setpoint active
- SP.2 2. setpoint activate active
- On Controller/signalling device and Limit 1 are switched on
- Off Controller/signalling device and Limit 1 are switched off
- Auto Automatic operation
- Man Manual operation
- Loc Local operation, adjustment possible via front panel
- rem Remote operation, adjustment possible via front panel not possible
- blc.P Configuration, parameter and calibration levels are blocked
- blc.C Configuration level is blocked
- u.blc All blocking cancelled

You can move through the list in the above sequence using the  key. Values are changed using   keys. The value is accepted using  key or automatically no more than 2 seconds after the change was made.

Return to normal operation by pressing the  key.

6 Operation



6.5 Self-optimisation (automatic adaption of control parameters)



t_i and t_d are only taken into account during the adaption, if they were not set to OFF previously.

When started by the operator, the controller initiates an adaptation attempt. During this attempt it calculates the parameters for fast control without overshoot to the setpoint using the characteristics of the control system.



Start of adaption:

The operator can start self-optimisation at any time. To do this, keys  and  are pressed simultaneously. In the second row, the active adaption is displayed flashing Ad:PIR. The controller outputs 0% control value, waits until the process has come to rest and begins the adaptation: Ad:Stp

The adaptation attempt is started by the controller when the following conditions are met:

- The difference between actual value / setpoint must be $\pm 10\%$ of the setpoint range (SP.Hi - SP.LO) (with inverse operation: actual value below setpoint, with direct operation: actual value above setpoint). If the adaption was successful, the AdA-LED is off and the controller continuous operating with the new control parameters.



Adaption cancelled by the operator:

The operator can cancel self-optimisation at any time. To do this, keys  and  are pressed simultaneously. The controller then continuous to operate in automatic mode with the old parameter values.


Adaption cancelled by the controller:

If an error is detected during the adaptation, technical control conditions exist which prevent a successful adaption.

In this case the adaption was cancelled by the controller. The controller switches off its outputs (control variable 0%), to avoid exceeding the setpoint. The operator has two possibilities to acknowledge a failed adaption:

1. Simultaneously pressing the  and  keys:

The controller continuous controlling in automatic mode using the old parameters. The adaption error must be acknowledged in the error list.


2. Pressing the  key:

Display of error list in extended operating level. Once the error message has been acknowledged, the controller continuous controlling in automatic mode using the old parameters

Cause of cancellation: See page 21 "Error status"

6 Operation

Examples for adaption attempts 3 point step controller



After the start ❶, the controller closes the correcting element (❷ out . 2). Once the difference between actual value and setpoint is sufficient ❸, the change of the actual value is monitored for 1 minute ❹. The correcting element is then opened (❺ out . 1). If the reversal point is reached ❻ or sufficient measurements have been taken, the parameters are determined and adopted.


6 Operation

6.6 Optimisation aid for manual optimisation

The optimisation aid should be used on devices, where the control parameters are to be set without self-optimisation.

The response of control variable x after a step change of correcting variable y can be used for this. It is often not possible to plot the complete response curve (0 to 100%), as the control variable must not exceed defined values.

Values T_g and x_{max} (step change from 0 to 100 %) or Δt and Δx (partial step response) can be used to determine the maximum rate of increase v_{max} .



Y = Correcting variable

Yh = Setting range

Tu = Delay time (s)

Tg = Recovery time (s)

x_{max} = Maximum value of control range

$$v_{max} = \frac{x_{max}}{Tg} = \frac{\Delta x}{\Delta t} = \text{max. rate of increase of control variable}$$

The control parameters can be determined from the values calculated for the delay time Tu, the maximum rate of increase v_{max} and the characteristic K according to the formulas given.

If the inlet to the setpoint is oscillating, Pb must be increased.

6 Operation

Adjustment aids

| Parameter | Control procedure | Fault condition | Start-up behaviour |
|------------|-------------------|---------------------|-----------------------------|
| Pb greater | increased damping | slower compensation | slower reduction of energy |
| less | decreased damping | faster compensation | faster reduction of energy |
| td greater | decreased damping | stronger reaction | earlier reduction of energy |
| less | increased damping | weaker reaction | later reduction of energy |
| ti greater | increased damping | slower compensation | slower reduction of energy |
| less | decreased damping | faster compensation | faster reduction of energy |

Formulas

| $K = V_{max} * T_u$ | Control behaviour | Pb [phys. units] | td [s] | ti [s] |
|---|-------------------------|------------------|-----------|-----------|
| With 2- and 3-point controllers the cycle time must be set to $t_1 \leq 0.25 * T_u$. | PID | $1.7 * K$ | $2 * T_u$ | $2 * T_u$ |
| | PD | $0.5 * K$ | T_u | OFF |
| | PI | $2.6 * K$ | OFF | $6 * T_u$ |
| | P | K | OFF | OFF |
| | 3-point step controller | $1.7 * K$ | T_u | $2 * T_u$ |

6 Operation

6.7 Manual operation

Depending on the controller currently in operation, the output of the controller can be adjusted manually.

Fig. 7: Continuous or switching controller




Fig. 8: 3-point step controller





Fig. 9: Stepping controller



6 Operation

6.8 Parameter setting and configuration

After switching on the power supply the device starts up with the **Operating Level**. The operating mode that was active prior to the restart is adopted.




Fig. 10: Overview operating level

7 Configuration level

7 Configuration level


7.1 Configuration with Quick



After exiting the configuration level (see page 27) the controller automatically undergoes a re-initialisation (all elements of the display are illuminated) and changes over to normal operation (operating level).

In the configuration level the function of the controller is stipulated by changing the configuration word Conf. In the lower display Conf and the code set are displayed alternately. Leading zeros are not displayed

Fig. 11: Configuration level



7 Configuration level

Code significance:

| | | |
|---|---|---|
| A | | Reaction at sensor break |
| | 0 | .. as actual value greater than setpoint |
| | 1 | .. as actual value less than setpoint |
| | 2 | P30/Ω connection .. as actual value less than setpoint) ¹ |
| B | | Configuring actual value input |
| | 0 | Remote transmitter 50-30-50Ω/ pressure transducer 0..10V, display range 0.0...100.0 (%) |
| | 1 | display range 0.00...1.00 (bar) |
| | 2 | display range 00...16.0 (bar) |
| | 3 | display range 0.0...40.0 (bar) |
| | 4 | Resistance thermometer Pt100, range 0...200°C |
| | 5 | Resistance thermometer Pt100, range 0...400°C |
| | 6 | Thermocouple type L, range 0...900°C |
| | 7 | Thermocouple type K, range 0...1350°C |
| C | | Control function |
| | 0 | Signalling device with change-over switch (SG) |
| | 1 | 3-point step controller (DPS) |
| | 2 | Continuous controller (PID) |
| | 3 | Switchable: (DPS) i (SG) |
| | 4 | (PID) i (SG) |
| | 5 | Switching controller (SR) |
| | 6 | Switchable: (DPS) i (SR) |
| | 7 | (PID) i (SR) |
| D | | Configuration OUT4 (analogue output) |
| | 0 | No output |
| | 1 | Control output for continuous controller) ² |
| | 2 | Control variable (INP1) |
| | 3 | Effective setpoint |
| | 4 | Control deviation |
| | 5 | 2 nd analogue input |
|) ¹ with A = 2 only B = 0...3 possible | | |
|) ² fixed for continuous controller (Func C = 2 4 7) | | |

Configuration example 1 (Code 0400):

Signalling device with change-over switch for two stage burners:

- Measuring range 0...200°C, resistance thermometer Pt 100,
- Reaction at sensor break as actual value greater than setpoint.

Configuration example 2 (Code 2120):

3-point step controller:

- Connection to pressure measurement transducer P30/Ω, measuring range 0.00...1.00 bar,
- Reaction at sensor break as actual value less than setpoint.

7 Configuration level

7.1.1 Function: Signalling device with change-over switch




Fig. 12: Signalling device with change-over switch

Settings (all parameters in physical values):

- Limit value d.SP3: If the limit value is exceeded, the relay is de-energised.
- Limit value d.SP2: If the limit value is exceeded, the relay is de-energised.
- Switch diff.: S.d3 / S.d2: If not maintained, the relay is re-energised.
- Upper limit value H.1: If the limit value is exceeded, the relay is de-energised.
- Switch differential HYS.1: If not maintained, the relay is re-energised.

Condition without power applied: all relays are de-energised, contacts open

Parameters: see chapter 8 "Parameter level"

7 Configuration level

7.1.2 Function: 3-point step controller




Fig. 13: 3-point step controller

Settings (in physical values):

Controller:

sh: Response threshold $A = 0.5 * sh$
Switch differential $Xsd = 0.06 * sh + 0.08$

tt: Runtime of actuator between burner partial load and full load: 3...9999 s
Minimum activation time: fixed, $TE_{min} = 100 \text{ ms}$

Control parameters: $Pb1 = 0.01...9999$: in physical values °C or °F
(number of digits behind the decimal point is determined by CON1)

$Ti = 1...9999 \text{ s}$ (OFF = no I portion)

$td = 1...9999 \text{ s}$ (OFF = no D portion)

Upper limit value H.1: If the limit value is exceeded, the relay is de-energised.

Switch differential HYS.1: If not maintained, the relay is re-energised.


Condition without power applied: all relays are de-energised, contacts open

Parameters: see chapter 8 "Parameter level"

7 Configuration level

7.1.3 Function: Switching controller

Fig. 14: Switching controller



Settings (in physical values):

Controller:

Smh: Switch on value full load (= 100% partial load)

t1: Minimum period at 50% switch signal

Minimum switch on duration: fixed, TEmin = 100 ms

Control parameters: Pb1 = 0.01...9999 : in physical values °C or °F

(number of digits behind the decimal point is determined by CON1)

Ti = 1...9999 s (OFF = no I portion)

td = 1...9999 s (OFF = no D portion)

Upper limit value H.1: If the limit value is exceeded, the relay is de-energised.

Switch differential HYS.1: If not maintained, the relay is re-energised.

Condition without power applied: all relays are de-energised, contacts open

Parameters: see chapter 8 "Parameter level"

7 Configuration level

7.2 Configuration without Quick (Quick = OFF)



This resets the controller to its default factory settings!

If, when powering up the controller the -key is pressed and held down, the configuration with **Quick** is switched off. Now all configuration settings are available to the user. To switch back to configuration with **Quick**, the keys must be pressed and held down when powering up the controller.

Overview of configuration:

Cntr

| Name | Value range | Description | Default | Own settings |
|-------|--------------|---|---------|--------------|
| SP.Fn | | Basic configuration of setpoint processing | 0 | |
| | 0 | Setpoint controller switchable to external setpoint (SP.E) | | |
| | 8 | Setpoint controller with external offset (SP.E) | | |
| C.Fnc | | Control behaviour (algorithm) | 7 | |
| | 1 | PID controller (2-point and continuous) | | |
| | 4 | 3-point step controller | | |
| | 7 | 3-point signalling device | | |
| | 9 | 3-point step controller switchable to 3-point signalling device | | |
| | 12 | Continuous controller switchable to 3-point signalling device | | |
| | 13 | Switching controller with intermediate load | | |
| | 14 | 3-point step controller switchable to switching controller with intermediate load | | |
| | 15 | Continuous controller switchable to switching controller with intermediate load | | |
| Man | | Manual adjustment permitted | 1 | |
| | 0 | non | | |
| | 1 | yes (see also LOGI / man) | | |
| C.Act | | Operating mode of controller | 0 | |
| | 0 | Inverse, e.g. heating | | |
| | 1 | Direct, e.g. cooling | | |
| Fail | | Behaviour at sensor break | 1 | |
| | 0 | Controller outputs switch off | | |
| | 1 | y = Y2 | | |
| | 2 | y = mean output. The maximum permissible output can be set with parameter Ym.H. To prevent unacceptable values being determined, averaging is only carried out if the control deviation is less than parameter L.Ym (only with C.Fnc = 2) | | |
| rnG.L | -1999...9999 | X0 (lower control range limit) ⁽¹⁾ | 0 | |
| rnG.H | -1999...9999 | X100 (upper control range limit) ⁽¹⁾ | 100 | |

⁽¹⁾ rnG.L and rnG.H indicate the control range, which relates to self-optimisation for example.

InP. 1

7 Configuration level

| Name | Value range | Description | Default | Own settings |
|-------|---|--|---------|--------------|
| S.tYP | | Sensor type | 50 | |
| | 0 | Thermocouple type L (-100...900°C) , Fe-CuNi DIN | | |
| | 1 | Thermocouple type J (-100...1200°C) , Fe-CuNi | | |
| | 2 | Thermocouple type K (-100...1350°C), NiCr-Ni | | |
| | 3 | Thermocouple type N (-100...1300°C), Nicrosil-Nisil | | |
| | 4 | Thermocouple type S (0...1760°C), PtRh-Pt10% | | |
| | 5 | Thermocouple type R (0...1760°C), PtRh-Pt13% | | |
| | 18 | Special thermocouple | | |
| | 20 | Pt100 (-200.0 ... 100.0 °C) | | |
| | 21 | Pt100 (-200.0 ... 850.0 °C) | | |
| | 22 | Pt1000 (-200.0...200.0 °C) | | |
| | 23 | KTY 11-6 (Special 0...4500 Ohm) | | |
| | 30 | 0...20mA / 4...20mA ⁽²⁾ | | |
| | 40 | 0...10V / 2...10V 2 | | |
| | 50 | Potentiometer 0...160 Ohm ⁽²⁾ | | |
| 51 | Potentiometer 0...450 Ohm ⁽²⁾ | | | |
| 52 | Potentiometer 0...1600 Ohm ⁽²⁾ | | | |
| S.Lin | | Linearisation (only at S.tYP = 30 (0..20mA) and 40 (0..10V) adjustable) | 0 | |
| | 0 | None | | |
| | 1 | Special linearisation. Creation of linearisation table with BlueControl (Engineering Tool) possible. The characteristics curve for KTY 11-6 temperature sensors is preset. | | |
| Corr | | Measured value correction / scaling | 2 | |
| | 0 | Without scaling | | |
| | 1 | Offset correction (in CAL level) | | |
| | 2 | 2-point correction (in CAL level) | | |
| | 3 | Scaling (in Para level) | | |

⁽²⁾ With current, voltage or potentiometer input signals scaling is required.

7 Configuration level

InP.2 (Option A)

| Name | Value range | Description | Default | Own settings |
|-------|--------------|--|---------|--------------|
| I.Fnc | | Function selection of INP2 | 0 | |
| | 0 | No function (the following Inp. data is skipped) | | |
| | 2 | External setpoint (switch-over -> LOGI/SP.E) | | |
| S.tYP | | Sensor type | 30 | |
| | 20 | Pt100 (-200.0 ... 100.0 °C) | | |
| | 21 | Pt100 (-200.0 ... 850.0 °C) | | |
| | 22 | Pt1000 (-200.0...200.0 °C) | | |
| | 23 | KTY11-6 (Special 0...4500 Ohm) | | |
| | 30 | 0...20mA / 4...20mA ⁽¹⁾ | | |
| | 50 | Potentiometer (0...160 Ohm) ⁽¹⁾ | | |
| | 51 | Potentiometer (0...450 Ohm) ⁽¹⁾ | | |
| | 52 | Potentiometer (0...1600 Ohm) ⁽¹⁾ | | |
| Corr | | Measured value correction / scaling | 0 | |
| | 0 | Without scaling | | |
| | 1 | Offset correction (in CAL level) | | |
| | 2 | 2-point correction (in CAL level) | | |
| | 3 | Scaling (in Para level) | | |
| In.F | -1999...9999 | Replacement value of INP2 | off | |

⁽¹⁾ With current, voltage or potentiometer input signals scaling is required (see Chapter 8.1)

Lim (Option 1)

(values can not be changed)

| Name | Value range | Description | Default | Own settings |
|-------|-------------|--|---------|--------------|
| Fnc.1 | | Function of limit value | 1 | |
| | 1 | <i>Measured value monitoring</i> | | |
| Fnc.2 | | Function of limit value | 0 | |
| Fnc.3 | | Function of limit value | 0 | |
| | 0 | <i>Switched off</i> | | |
| Src.1 | | Source for limit value | 1 | |
| | 1 | <i>Control deviation X_w (actual value - setpoint) = relative alarm</i> | | |

7 Configuration level

Out. 1/2 (Option 2)

| Name | Value range | Description | Default | Own settings |
|------------|-------------|---------------------------------------|----------------------|--------------|
| O.Act | | Operating mode of output | Out.1= 0 Out.2= 0 | |
| | 0 | Direct / open circuit principle | | |
| | 1 | Inverse / closed circuit principle | | |
| Y.1 | | Controller / signalling device output | Out.1= 1 Out.2= 0 | |
| Y.2 | | Controller / signalling device output | Out.1= 0 Out.2= 1 | |
| Lim.1 | | Limit value signal | 0 | |
| FAi.1FAi.2 | | INP1 / INP2 error signal | 0 | |
| | 0 | <i>not active</i> | | |
| | 1 | <i>active</i> | | |

(Values can not be changed)

Out. 3 (Option 1)

| Name | Value range | Description | Default | Own settings |
|----------------|-------------|---------------------------------------|---------|--------------|
| O.Act | | Operating mode of output | 1 | |
| | 0 | Direct / open circuit principle | | |
| | 1 | Inverse / closed circuit principle | | |
| Y.1 Y.2 | | Controller / signalling device output | 0 | |
| Lim.1 | | Limit value 1signal | 1 | |
| FAi.1 FAi.2 | | INP1 / INP2 error signal | 0 | |
| | 0 | <i>not active</i> | | |
| | 1 | <i>active</i> | | |

(Values can not be changed)

7 Configuration level

Out.4 (Option A)

| Name | Value range | Description | Default | Own settings |
|-------|-------------|--|---------|--------------|
| O.typ | | Signaltyp | 3 | |
| | 0 | <i>Relay / Logic</i> | | |
| | 1 | 0..20mA continuous | | |
| | 2 | 4..20mA continuous | | |
| | 3 | 0..10V continuous | | |
| | 4 | 2..10V continuous | | |
| | 5 | <i>Transmitter power supply</i> | | |
| Out.0 | | Scaling 0% | 0 | |
| Out.1 | | Scaling 100% | 100 | |
| O.Src | | Source for signal output | 3 | |
| | 0 | No output | | |
| | 1 | Control output for continuous controller | | |
| | 3 | Control variable (INP1) | | |
| | 4 | Effective setpoint | | |
| | 5 | Control deviation | | |
| | 8 | 2 nd analogue input | | |
| | | | | |

7 Configuration level

LOGI

| Name | Value range | Description | Default | Own settings |
|-------|-------------|--|---------|--------------|
| L_r | | Local / Remote change-over (Remote: Adjustment of values via front panel is blocked) | 0 | |
| | 0 | No function | | |
| | 1 | Always active | | |
| | 5 | F-key menu | | |
| SP.2 | | Change-over to second setpoint SP.2 | 3 | |
| | 0 | No function | | |
| | 3 | DI2 switches | | |
| | 5 | F-key menu | | |
| SP.E | | Change-over to external setpoint SP.E | 0 | |
| | 0 | No function | | |
| | 1 | Always active | | |
| | 3 | DI2 switches | | |
| | 5 | F-key menu | | |
| man | | Automatic/Manual change-over | 0 | |
| | 0 | No function | | |
| | 5 | F-key menu | | |
| C.off | | Switches off the controller | 0 | |
| | 0 | No function | | |
| | 5 | F-key menu | | |
| Err.r | | Resets all error list entries | 0 | |
| | 0 | No function | | |
| | 5 | F-key menu | | |
| di.Fn | | Function of digital inputs (valid for all inputs) | 0 | |
| | 0 | Direct | | |
| | 1 | Inverse | | |
| | 2 | Key function | | |

7 Configuration level

othr

| Name | Value range | Description | Default | Own settings |
|-------|-------------|---------------------------------------|---------|--------------|
| Baud | | Baudrate | 2 | |
| | 0 | 2400 | | |
| | 1 | 4800 | | |
| | 2 | 9600 | | |
| | 3 | 19200 | | |
| Addr | 1..247 | Device address | 1 | |
| Prty | | Parity | 1 | |
| | 0 | None 2 Stop bits | | |
| | 1 | Even | | |
| | 2 | Odd | | |
| | 3 | None 1 Stop bit | | |
| Delay | 0.. 200 | Response delay [ms] | | |
| Unit | | Unit | 1 | |
| | 0 | No unit | | |
| | 1 | °C | | |
| | 2 | °F | | |
| dP | | Decimal point (max. number of digits) | 0 | |
| | 0 | No digit behind decimal point | | |
| | 1 | 1 digit behind decimal point | | |
| | 2 | 2 digit behind decimal point | | |
| | 3 | 3 digit behind decimal point | | |
| C.dEL | 0...200 | Modem delay [ms] | 0 | |

8 Parameter level

8 Parameter level

Cntr

| Bei Quick sichtbar | Name | Value range | Description | Default | Own settings |
|--------------------|-------|--------------|--|---------|--------------|
| x | Pb | 1...9999 | Proportional range 1 (heating) in phys. unit (e.g. °C) | 10 | |
| x | ti | 1...9999 | Integral action time 1 (heating) [s] | 10 | |
| x | td | 1...9999 | Derivative action time 1 (heating) [s] | 10 | |
| | t1 | 0.4...9999 | Minimum cycle duration [s]. Minimum impulse = $t_1 / 4$ | 10 | |
| x | SH | 0...9999 | Neutral zone, or switch differential signalling device [phys. unit] | 1 | |
| x | Sd2 | 0.0...9999 | Switch differential intermediate load for signalling device | 0.1 | |
| x | d.SP2 | -1999...9999 | Switch point distance intermediate load | 0 | |
| x | Sd3 | 0.0...9999 | Switch differential full load for signalling device | 0.1 | |
| x | d.SP3 | -1999...9999 | Switch point distance full load | 0 | |
| x | tP | 0.1...9999 | Minimum impulse duration [s] | OFF | |
| x | tt | 3...9999 | Actuator run time [s] | 60 | |
| x | S.mH | 0...100% | Capacity at 100% intermediate load | 70 | |
| | Y.Lo | -105...105 | Lower control variable limit [%] | 0 | |
| | Y.Hi | -105...105 | Upper control variable limit [%] | 100 | |
| | Y2 | -100...100 | Second control value [%] | 0 | |
| | Y.0 | -105...105 | Operating point for control variable [%] | 0 | |
| | Ym.H | -105...105 | Limit of the mean value Ym [%] | 5 | |
| | L.Ym | 1...9999 | Max. deviation xw, at the start of mean value calculation [phys. unit] | 8 | |

SEtP

| Visible with Quick | Name | Value range | Description | Default | Own settings |
|--------------------|-------|--------------|-------------------------------|---------|--------------|
| | SP.LO | -1999...9999 | Lower setpoint limit for Weff | 0 | |
| | SP.Hi | -1999...9999 | Upper setpoint limit for Weff | 100 | |
| x | SP.2 | -1999...9999 | Second setpoint | 10 | |
| | r.SP | 0...9999 | Setpoint gradient [/min] | OFF | |
| | t.SP | 0...9999 | Start-up hold time | 5.0 | |

InP.1

| Visible with Quick | Name | Value range | Description | Default | Own settings |
|--------------------|-------|--------------|--------------------------------------|---------|--------------|
| | InL.1 | -1999...9999 | Input value of lower scaling point | 38.5 | |
| | OuL.1 | -1999...9999 | Display value of lower scaling point | 0 | |
| | InH.1 | -1999...9999 | Input value of upper scaling point | 61.5 | |
| | OuH.1 | -1999...9999 | Display value of upper scaling point | 100 | |
| | t.F1 | 0.0...100.0 | Filter time constant [s] | 0.5 | |

8 Parameter level

InP.2

| Visible with Quick | Name | Value range | Description | Default | Own settings |
|--------------------|-------|--------------|--------------------------------------|---------|--------------|
| | InL.2 | -1999...9999 | Input value of lower scaling point | 0 | |
| | OuL.2 | -1999...9999 | Display value of lower scaling point | 0 | |
| | InH.2 | -1999...9999 | Input value of upper scaling point | 100 | |
| | OuH.2 | -1999...9999 | Display value of upper scaling point | 100 | |
| | t.F2 | 0.0...100.0 | Filter time constant [s] | 0.5 | |

Lim

| Visible with Quick | Name | Value range | Description | Default | Own settings |
|--------------------|-------|--------------|-----------------------------|---------|--------------|
| x | H.1 | -1999...9999 | Upper limit value 1 | 20 | |
| x | HYS.1 | 0...9999 | Hysteresis of limit value 1 | 0.1 | |

8 Parameter level

8.1 Input scaling (only visible with Quick= OFF)

When using current or voltage signals as input variables for **InP.1** or **InP.2**, scaling of input and display values is required in the parameter setting level. The specification of the input value of the lower and upper scaling point is indicated in the respective electrical size (mA/ V).

8.1.1 Input Inp.1

Parameters **InL.1**, **OuL.1**, **InH.1** and **OuH.1** are only visible, if **ConF / InP.1 / Corr = 3** was selected.

| S.tYP | Input signal | InL.1 | OuL.1 | InH.1 | OuH.1 |
|------------------|--------------|-------|----------|-------|----------|
| 30 (0...20mA) | 0 ... 20 mA | 0 | optional | 20 | optional |
| | 4 ... 20 mA | 4 | optional | 20 | optional |
| 40 (0...10V) | 0 ... 10 V | 0 | optional | 10 | optional |
| | 2 ... 10 V | 2 | optional | 10 | optional |

In addition to these settings, **InL.1** and **InH.1** can be adjusted in the range (0...20mA / 0...10V) stipulated by selecting **S.tYP**.

If standard scaling is to be applied when using thermocouples and resistance thermometers (Pt100), the settings of **InL.1** and **OuL.1** as well as **InH.1** and **OuH.1** must correspond. If changes of the input scaling were made in the calibration level (page 43), these are shown in the input scaling in the parameter level. If the calibration is reset (OFF), the scaling parameters are reset to the default setting.

8.1.2 Input InP.2

As input **InP.1**, but only if **S.Typ = 30** is set!

9 Calibration level

9 Calibration level



Measured value correction (CAL) only visible if
ConF / InP.n / Corr = 1 or 2 and Quick = OFF were selected.

An adjustment of the measured value can be made in the calibration menu (CAL).

Two methods are available:

- Offset correction
- 2-point correction




Fig. 15: Calibration level


The parameters (OuL.n, OuH.n) changed in the CAL level can be reset by setting the parameters below the lowest setting value using the key (OFF).

9 Calibration level


9.1 Offset correction




(ConF / InP.n / Corr = 1):


- can be made online at the process



9 Calibration level

InL.n: Here, the input value of the scaling point is displayed.
The operator must wait until the process is at rest. Subsequently, the operator acknowledges the input value by pressing the -key.

OuL.n: Here, the display value of the scaling point is displayed.
Prior to calibration OuL.n is equal to InL.n. The operator can correct the display by pressing the  -keys. The display value is confirmed by pressing the -key.




9 Calibration level


9.2 2-point correction




(ConF / InP.n / Corr = 2):


- can be made offline using actual value generator or
- online in 2 steps, by initially correcting the first value and then subsequently, the second value, for example once the oven has heated up.







9 Calibration level

InL.n: The input value of the lower scaling point is displayed. The operator must wait until the process is at rest. Subsequently, the operator acknowledges the input value by pressing the -key.

OuL.n: The display value of the lower scaling point is displayed. Prior to calibration OuL.n is equal to InL.n. The operator can correct the lower display value by pressing the  -keys. The display value is confirmed by pressing the -key.

InH.n: The input value of the upper scaling point is displayed. The operator must wait until the process is at rest. Subsequently, the operator acknowledges the input value by pressing the -key.

OuH.n: The display value of the upper scaling point is displayed. Prior to calibration OuH.1 is equal to InH.1. The operator can correct the upper display value by pressing the  -keys. The display value is confirmed by pressing the -key..



10 Optional plug-in modules

10 Optional plug-in modules


10.1 Optional modules and their function



Modules for socket 1-3 can not be fitted to socket A. Only modules for socket A can be fitted to this socket. Please refer to table 1 – Optional Modules for more details.

Various optional plug-in modules are available for additional input, output and communication functions. These modules are installed during production or retrofitted to devices already delivered.


Fig. 16: Sockets



The modules are fitted to the four optional sockets between the main circuit boards of the device. The designations for these sockets are 1,2,3, and A. The installation is shown in figure 17.

10 Optional plug-in modules

Fig. 17: View of the open device with PCB position



10.1.1 Automatic recognition of optional modules

The device automatically recognises, which optional module is fitted to which socket. If this recognition detects a discrepancy to the HW-Code (factory setting) set, the error message **E.4** is displayed.

Table 1 – optional modules available

| Optional modules | |
|---------------------------|------------------|
| Model code | KS20 - 1 O P - x |
| Option 3 | ↓ |
| Linear output mA/VDC | L |
| RS485 | C |
| Relay output | R |
| DC control output for SSR | S |

10.1.2 Preparation for installing or removing optional modules



Ensure that all connections on the rear of the device have been removed and isolated prior to removing the device from the housing.

Remove the device from the housing by gripping the sides of the front plate (a recessed handle is located on each side) and pulling the device forward and out. The device is released from the fixture on the rear and the circuit boards become accessible.

Memorise the installation position of the device for refitting to the housing. The positions for the main and optional circuit boards in the device are shown in figure 18.

10 Optional plug-in modules

10.1.3 Removing/replacing optional modules

After removing the device from the housing, proceed as follows:

To remove or replace the modules in the optional socket 1-3, carefully disconnect the CPU and PSU circuit boards from the front plate.

- 1 Remove the main circuit boards (PSU and CPU) from the front plate.
- 2 Lift the top and then the bottom mounting clamp to remove the circuit boards from the front plate.

If only the optional socket A has to be replaced, this step is not necessary (in this case, the circuit boards are accessible without disconnecting the main circuit boards from the front plate).

Now you can start installing or removing the modules. The connections are shown below. The fixing lugs of the optional modules fit into the cut-outs of the main circuit board (either opposite or next to the connections).




Abb. 18: Mounting position of the optional modules

- ❶ Display PCB
- ❷ Control PCB
- ❸ Power supply PCB
- ❹ Optional modules 1...3
- ❺ Adapter module
- ❻ Optional module 4




The adapter module must always be fitted when using optional module 3.



Pay attention to the correct mounting position of the modules and make sure that the connector pins are fully inserted.

10 Optional plug-in modules

Fig. 19: Sockets for optional modules



①②③④ Optional modules

⑤ Adapter module

10.1.4 Inserting the device into the housing

Once the desired optional module is correctly installed in the appropriate position, the device can be inserted into the housing:

- 1 Carefully push together the CPU and PSU circuit boards and ensure that the fixing lugs of the optional modules lock into the opposite slots. Hold the circuit boards together and reinsert them into the front plate mounting.
- 2 Insert the two circuit boards into the guides and re-establish the connection to the housing. Ensure the modules are mounted in the correct position and ensure that the connection pins are fully inserted into the front plate.
- 3 Carefully push the device into the correct position.

11 Maintenance

11 Maintenance



Live parts and terminals may be exposed when opening the device or when removing covers or components. Connection points may also be live.

The device must be disconnected completely from the power supply prior to starting this work.

The devices require no special maintenance.

11.1 Reset to factory setting

Press and hold the following keys during power-on:



12 Notes

12 Notes

Key word index

| | | | |
|--|-------|---|----|
| 2 | | | |
| 2-point correction | 46 | | |
| 3 | | | |
| 3-point step controller | 31 | | |
| A | | | |
| Alterations to the construction of the equipment | 7 | | |
| C | | | |
| Calibration level | 43 | | |
| Commissioning | 7 | | |
| Configuration level | 28 | | |
| Configuration with Quick | 28 | | |
| Configuration without Quick | 33 | | |
| Current and voltage measuring ranges | 14 | | |
| D | | | |
| Disposal | 8 | | |
| E | | | |
| Electrical connection | 7, 17 | | |
| Error list | 20 | | |
| Error status | 21 | | |
| F | | | |
| Front view | 18 | | |
| G | | | |
| Guarantee | 6 | | |
| I | | | |
| Inputs | 10 | | |
| Installation | 15 | | |
| M | | | |
| Maintenance | 8, 52 | | |
| Manual operation | 26 | | |
| O | | | |
| Offset correction | 44 | | |
| Operating level | 19 | | |
| Operation | 18 | | |
| Optimisation aid | 24 | | |
| Optional plug-in modules | 48 | | |
| Outputs | 11 | | |
| P | | | |
| Parameter level | 40 | | |
| Parameter setting and configuration | 27 | | |
| Power supply | 12 | | |
| Product description | 9 | | |
| R | | | |
| Reset to factory setting | 52 | | |
| Resistance transducer measuring ranges | 14 | | |
| S | | | |
| Safety notes | 7 | | |
| Self-optimisation | 22 | | |
| | | Shutdown | 8 |
| | | Signalling device with change-over switch | 30 |
| | | Switching controller | 32 |
| | | Symbols | 5 |
| | | T | |
| | | Target group | 5 |
| | | Technical data | 10 |
| | | Thermocouple measuring ranges | 13 |
| | | Type key | 9 |
| | | U | |
| | | User guide | 5 |

The complete program: Reliable technology and prompt, professional service

| | | | |
|---|---|--|---|
|  | <p>W Burners up to 570 kW</p> <p>The compact burners, proven millions of times over, are economical and reliable. Available as gas, oil and dual fuel burners for domestic and commercial applications.</p> <p>The purflam® burner version with special mixing head gives almost soot-free combustion of oil with greatly reduced NOx emissions.</p> | <p>Wall-hung condensing boilers for oil and gas up to 240 kW</p> <p>The wall-hung condensing boilers WTC-GW and WTC-OW have been developed to meet the highest demands in ease of operation and efficiency.</p> <p>Modulating operation means these units operate quietly and economically.</p> |  |
|  | <p>monarch® WM Burners and Industrial Burners up to 11,700 kW</p> <p>These legendary industrial burners are durable and versatile.</p> <p>Numerous variations of oil, gas and dual fuel burners meet a wide range of applications and capacity requirements.</p> | <p>Floor standing condensing boiler for oil and gas up to 1,200 kW</p> <p>The floor-standing boilers WTC-GB and WTC-OB are efficient, low in emissions and versatile. Higher capacities are achieved by cascading up to four gas-fired condensing boilers.</p> |  |
|  | <p>WK Burners up to 28,000 kW</p> <p>These industrial burners of modular construction are adaptable, robust and powerful.</p> <p>Even on the toughest industrial applications these oil, gas and dual fuel burners operate reliably.</p> | <p>Solar systems</p> <p>The stylish flat-plate collectors are the ideal complement for any Weishaupt heating system. They are suitable for solar water heating and for combined heating support.</p> <p>With versions for on-roof, in-roof and flat roof installations, solar energy can be utilised on almost any roof.</p> |  |
|  | <p>multiflam® Burners up to 17,000 kW</p> <p>This innovative Weishaupt technology for medium and large burners provides minimum emission values at capacities up to 17 MW.</p> <p>The burners with the patented mixing head are available for oil, gas and dual fuel operation.</p> | <p>Water heaters / energy storage tanks</p> <p>This attractive program for domestic water heating includes classic water heaters, solar storage tanks, heat pump storage tanks and energy storage tanks.</p> |  |
|  | <p>MCR Technology / Building Automation from Neuberger</p> <p>From control panels to complete building management systems - at Weishaupt you can find the entire spectrum of modern control technology. Future orientated, economical and flexible.</p> | <p>Heat pumps up to 130 kW</p> <p>The heat pump range offers solutions for the utilisation of heat from the air, the soil or ground water.</p> <p>Some systems are also suitable for cooling buildings.</p> |  |
|  | <p>Service</p> <p>Weishaupt customers can be assured that specialist knowledge and tools are available whenever they are needed. Our service engineers are fully qualified and have extensive product knowledge, be it for burners, heat pumps, condensing boilers or solar collectors.</p> | <p>Geothermal probe drilling</p> <p>With its daughter company, BauGrund Süd, Weishaupt also offers geothermal probe and well drilling. With the experience of more than 10,000 systems and more than 2 million meters of drilling, BauGrund Süd offers a comprehensive service program.</p> |  |